

Overcoming High Humidity in Operating Rooms

John Hayes
Application Consultant
Mingledorff's, Inc.
North Alabama District



I got a speeding ticket!



Yes or No?

- Do you get comfort complaints from surgeons regarding the Operating Room (OR)?
- Is the relative humidity (RH) higher than 50% in your OR?
- Would you like to save as much as 40% energy cost when treating the Outdoor Air for an OR?



If you answered YES

- Let's start with Why?



Why?

- Wasn't the OR designed by a group of professionals – an architect and engineers?
- Didn't those professionals rely on standards and the local code to ensure great success?
- Didn't the plans get reviewed before construction began?
- Wasn't the installation performed by licensed contractors?
- Didn't someone sign off on the final product?



Standards and Codes

- **American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE)**
- **Facility Guidelines Institute (FGI)**
- **Joint Commission**
- **National Institutes of Health (NIH)**
- **QUAD A (The Global Accreditation Authority)**



So, why is there high humidity?



So, why is there high humidity?

- What about the surgeon?



So, why is there high humidity?

- What about the surgeon?
- What about those using the OR during the occupied period?



So, why is there high humidity?

- What about the surgeon?
- What about those using the OR during the occupied period?
- Did these folks get to weigh in based on their preferences/requirements?




Standards vs. Surgeon Preference

- ASHRAE Standard 170, among other things, addresses temperature and humidity and ventilation rates
 - 68 to 75 degrees F (a dry bulb measurement)
 - 20% to 60% Relative Humidity (RH)
 - 4 Outdoor Air Changes per hour
 - 20 Supply Air Changes per hour
- Surgeon preference:
 - Low to middle 60s F
 - “If 60% RH is the best we can get, okay” but...



Effect of Room Relative Humidity on Selected Human Health Parameters




¹ Insufficient data above 50% R.H.

Source: Sterling (1984) ASHRAE Transactions V. 90, Part 2.



Effect of Room Relative Humidity on Selected Human Health Parameters



¹ Insufficient data above 50% R.H.

Source: Sterling (1984) ASHRAE Transactions V. 90, Part 2.



Scenarios and Outcomes

- Warning
- The next slides capture design conditions allowed by the standard at 68 F to 75 F and RH between 20% and 60%






The Engineering Tool Box

www.EngineeringToolBox.com

PSYCHROMETRIC CHART

BAROMETRIC PRESSURE 29.921 inches of Mercury






The Engineering Tool Box

www.EngineeringToolBox.com

PSYCHROMETRIC CHART

BAROMETRIC PRESSURE 29.921 inches of Mercury






The Engineering Tool Box

www.EngineeringToolBox.com

PSYCHROMETRIC CHART

BAROMETRIC PRESSURE 29.921 inches of Mercury






The Engineering Tool Box

www.EngineeringToolBox.com

PSYCHROMETRIC CHART

BAROMETRIC PRESSURE 29.921 inches of Mercury






The Engineering Tool Box

www.EngineeringToolBox.com

PSYCHROMETRIC CHART

BAROMETRIC PRESSURE 29.921 inches of Mercury






The Engineering Tool Box

www.EngineeringToolBox.com

PSYCHROMETRIC CHART

BAROMETRIC PRESSURE 29.921 inches of Mercury



Practical approaches to lower humidity

- We observed that DX and chilled water systems alone cannot get space relative humidity low enough to be in an acceptable range of the standard – especially when surgeons are asking for lower OR temps
- A low temp chiller can get you there with a 65 degree space temp – using a lot of energy!
- But there is a real solution...



Desiccants!



Desiccants

- What is a desiccant?
- Why desiccants?
- Types of desiccant:



Desiccants

- What is a desiccant?
 - Anything with an affinity for moisture
- Why desiccants?
- Types of desiccant:



Desiccants

- What is a desiccant?
 - Anything with an affinity for moisture
- Why desiccants?
 - They capture more moisture than saturated coils
 - They are efficient – they save utility costs!
- Types of desiccant:



Desiccants

- What is a desiccant?
 - Anything with an affinity for moisture
- Why desiccants?
 - They capture more moisture than saturated coils
 - They are efficient – they save utility costs!
- Types of desiccant:
 - Liquid
 - Solid



Types of solid desiccant systems

- Passive
- Active



Types of solid desiccant systems

- Passive
 - Limited dewpoint depression 8 – 12 grains
- Active



Types of solid desiccant systems

- Passive
 - Limited dewpoint depression 8 – 12 grains
- Active
 - Removal of 40 or more grains, or
 - Reduction in dewpoint - around 19 degrees!






The Engineering Tool Box


www.EngineeringToolBox.com

PSYCHROMETRIC CHART


BAROMETRIC PRESSURE 29.921 inches of Mercury



Active regeneration with condenser heat



Active regeneration with condenser heat



- Active desiccant systems are ideal for retrofit or new construction
- Offer 40% reduction in compressor chilled water capacity and are more efficient if incorporating energy recovery
- DX or CW
- Condenser heat or other heat sources to regenerate the desiccant wheel



Questions?

John Hayes

Application Consultant

Mingledorff's, Inc.

North Alabama District

205-368-6952 (Cell)

jhayes@mingledorffs.com

